



Ethernet from PropNIC  
<http://www.ucontroller.com/documentation/PropNICDoc.html>

PROTOTYPE AREA  
 PIN\_ARRA#0X02  
 PIN\_ARRA#0X02  
 PIN\_ARRA#0X02  
 PIN\_ARRA#0X02